





PE Ball Valve

INSTALLATION GUIDELINES AND WARNINGS

Installation	Use	Warnings
<ul style="list-style-type: none"> ● Observe local installation standards, manuals and drawings ● Observe standard butt fusion or electrofusion installation methods ● Protect products by storing indoors and in plastic bags protecting cap before installation 	<ul style="list-style-type: none"> ● Handle : 50mm square type for all sizes ● Connection : after attaching key extension put the handle at the top of the extension ● Open/Close method for lever or gear type valve <ul style="list-style-type: none"> - In order to close, turn clockwise 90° from Open location - In order to open, turn counterclockwise 90° from Close location  <p style="text-align: center;">◆ Lever type operator</p>  <p style="text-align: center;">◆ Gear type operator</p>	<div style="text-align: center;">  </div> <ol style="list-style-type: none"> 1. Handle with care in order to avoid damaging the valve 2. Follow proper installation methods and use only in appropriate applications 3. For use in approved natural gas and water applications 4. Always keep the valve clean and free from internal and external debris 5. Do not apply excessive force when opening and closing the valve 6. Keep the valve away from flames and excessive heat 7. This valve cannot be disassembled or repaired 8. Appropriate support of valve is critical in all buried and above ground installations
<p>COSMOIND USA, Inc. 1941 Haw River Hopedale Rd, Burlington, NC 27217 USA Tel. (336) 270-4333 www.cosmoindusa.com</p>		